



Dell Studio 1737 Battery replacement

This guide will demonstrate how to remove the battery from a Dell Studio 1737


Written By: Joseph Jacavone



INTRODUCTION

This guide will demonstrate how to remove the battery from a Dell Studio 1737

Step 1 — Battery



- Slide the battery release slider all the way to the right and push the battery straight out of the back of the computer

To reassemble your device, simply slide the battery back into the slot it came from and the slider will latch it in place.

This document was last generated on 2017-08-22 08:05:43 AM.